



**Catrike Adjustable Handlebars  
2006 Models Standard**

Big Cat HPV. LLC  
720 Business Park Blvd Ste 22  
Winter Garden, FL 34787

## Catrike Adjustable Handlebars 2006 Models Standard (option \$99/pair: Fits All 2004/2005 Direct Steering)

Your new Catrike adjustable handlebars can be adjusted in many ways to give each Catrike owner a custom fit. The only tool needed is an 5mm allen key.



The long, horizontal portion of the handlebar has a gentle incline to it. For those riders who prefer lower handlebars, this can be installed upside down to provide a gentle downward slope.

The same holds true for the shorter grip portion of the handlebar. It has a gentle angle leaning forward, but can be reversed. You can see the difference in mounting in the pictures below.



The picture on the top shows the recommended standard setup.

The handlebar sets come in left and right sides. When mounting them upside down, simply swap sides to keep the heads of the screws on the inside of the trike, making them easier to reach with the allen key.

**NOTE:** *Be sure the tightening bolts are completely loosened before attempting to move or rotate the short grip portion of the handlebar to avoid scratching the paint.*



They can be adjusted to be long or short for better ergonomics. When adjusting the handlebars in short, the excess post can be used for mounting mirrors or a computer.

Catrike Adjustable Handlebars 2006 Models Standard



They can be adjusted wide out for a better turning radius or in close to the body for better aerodynamics.



The “twist” of the grip portion of the handlebar is also fully adjustable.